


SETUP (BEFORE FIRST USE)



Unscrew and remove the Pump Handle from the Bottle and turn upside down to confirm o-ring is present and seated securely inside Pump Handle neck.



Ensure thick White Tube with the stainless steel pump has been properly threaded and tightened.



Tighten the Colored Nozzle to Pump Handle.

QUESTIONS/COMMENTS/SUGGESTIONS? E-MAIL US AT CONTACT@COREGEARUSA.COM OR VISIT COREGEARUSA.COM/FAQ/

INSTRUCTIONS

- Fill the bottle to the fill line. Do not over fill.
- Install the included Carrying Strap and Bag Clip. Small loop of Carrying Strap goes around neck of Pump Handle.
- Screw the Pump Handle onto the bottle evenly and securely taking care not to get Carrying Strap caught in threads.
- Lift and lower rounded Pump Rod 10 times (or until you feel resistance) to pressurize. Do not over pump.
- Adjust brass nozzle tip all the way to the left for a mist or 1/4 turn to the right for a spray.
- Depress the trigger at top of Pump Handle for continuous mist or spray.